




Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD, .....


- 1 - B 961853 XX
- 2 - A 963751 NU
- 3 - B 961373 XX
- 4 - B 961374 NU
- 5 - A 861181 NU
- 6 - A 861156 NU
- 7 - B 960754 XX
- 8 - A 964520 NU
- 9 - B 960900 XX
- 10 - A 962991 XX
- 11 - A 960063 XX




**Ideal Standard**




## CERABASE

08.2022 / B565250



Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium  
<http://www.idealstandardinternational.com>





|  |   |     |  |         |  |    |  |       |         |
|--|---|-----|--|---------|--|----|--|-------|---------|
|  | P | bar |  | MAX. 10 |  | 5  |  | Q     | (3 bar) |
|  | T | °C  |  | MAX. 80 |  | 65 |  | I/min | 5       |