


09 20 71 031



	Chrom	09 20 71 031-00
	Platin gebürstet	09 20 71 031-06
	Dark Chrome	09 20 71 031-19
	Light Gold gebürstet	09 20 71 031-27
	Champagne gebürstet (22kt Gold)	09 20 71 031-46
	Champagne (22kt Gold)	09 20 71 031-47
	Dark Platinum gebürstet	09 20 71 031-99



Zugknopf für Ablaufgarnitur - Chrom

ERSATZTEILE

09 20 71 031



Zugknopf für Ablaufgarnitur - Chrom

ERSATZTEILE

09 20 71 031