















- | | |
|----|----------------|
| 01 | 00181620000001 |
| 02 | 00185907000002 |
| 03 | 00183608000001 |
| 04 | 00183108000001 |
| 05 | 00186020000001 |



DE	Gebrauchsanleitung / Montageanleitung
GB	Instructions for use / Assembly instructions
DK	Bruksanvisning / Monteringsvejledning
FR	Mode d'emploi / Instructions de montage
NL	Gebruiksaanwijzing / Handleiding
NO	Bruksanvisning / Montasjeveiledning
PL	Instrukcja obsługi / Instrukcja montażu
PT	Instruções para uso / Manual de instalação
CZ	Návod k použití / Montážní návod
HU	Használási útmutató / Szerelési útmutató
SV	Bruksanvisning / Monteringsanvisning
ES	Modo de empleo / Instrucciones de montaje
RU	Пособие по монтажу / Инструкция по монтажу
IT	Istruzioni per l'installazione / Istruzioni per l'uso
SK	Montážny návod / Návod na použitie



 Schlösser Armaturen GmbH & Co. KG
Im Dohm 3
57462 Olpe
GERMANY
www.schloesser-armaturen.de
info@schloesser-armaturen.de

