



09 27 97 015



| | | |
|---|---------------------------------|-----------------|
|  | Chrom | 09 27 97 015-00 |
|  | Platin gebürstet | 09 27 97 015-06 |
|  | Platin | 09 27 97 015-08 |
|  | Weiß matt | 09 27 97 015-10 |
|  | Dark Brass matt | 09 27 97 015-16 |
|  | Dark Bronze matt | 09 27 97 015-17 |
|  | Dark Chrome | 09 27 97 015-19 |
|  | Light Gold | 09 27 97 015-26 |
|  | Light Gold gebürstet | 09 27 97 015-27 |
|  | Messing gebürstet (23kt Gold) | 09 27 97 015-28 |
|  | Schwarz matt | 09 27 97 015-33 |
|  | Dark Brass gebürstet | 09 27 97 015-39 |
|  | Bronze gebürstet | 09 27 97 015-42 |
|  | Champagne gebürstet (22kt Gold) | 09 27 97 015-46 |
|  | Champagne (22kt Gold) | 09 27 97 015-47 |
|  | Cyprum | 09 27 97 015-49 |
|  | Chrom gebürstet | 09 27 97 015-93 |
|  | Dark Platinum gebürstet | 09 27 97 015-99 |



Rosette DB Logo Ø 60 x 9 mm - Chrom

ERSATZTEILE

09 27 97 015



Rosette DB Logo Ø 60 x 9 mm - Chrom

ERSATZTEILE

09 27 97 015