














Im Dohm 3

GERMANY

info@schlosser-armaturen.de



DE	Gebrauchsanleitung / Montageanleitung
GB	Instructions for use / Assembly instructions
DK	Bruksanvisning / Monteringsvejledning
FR	Mode d'emploi / Instructions de montage
NL	Gebruiksaanwijzing / Handleiding
NO	Bruksanvisning / Montasjerveiledning
PL	Instrukcja obsługi / Instrukcja montażu
PT	Instruções para uso / Manual de instalação
CZ	Návod k použití / Montážní návod
HU	Használati útmutató / Szerelési útmutató
SV	Bruksanvisning / Monteringsanvisning
ES	Modo de empleo / Instrucciones de montaje
RU	Руководство пользователя / Инструкция по монтажу
IT	Istruzioni per l'installazione / Istruzioni per l'uso
SK	Montážny návod / Návod na použitie



0015053200001

01	0018163200001
02	0018590800001
03	0018603200001

DIN 1988
DIN 3502
DIN EN 1213