






1




2




3




4




5




6




1



2








DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BG Brugsanvisning / Monteringsvejledning
DK Mode d'emploi / Instructions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjehandleiding
NO Instruksjon for bruk / Manual de instalación
PL Instrukcja obsługi / Instrukcja montażu
CZ Návod k použití / Montážní návod
HU Használati útmutató / Szerelési útmutató
SV Bruksanvisning / Monteringsanvisning
ES Modo de empleo / Instrucciones de montaje
RU Руководство пользователя /
Инструкция по монтажу
IT Istruzioni per l'uso / Istruzioni per l'uso
SK Montážny návod / Návod na použitie



Schlösser Armaturen GmbH & Co. KG
Im Dohm 3
57462 Olpe
GERMANY
www.schloesser-armaturen.de
info@schloesser-armaturen.de



0015383500001

01 0018183200001
02 0018590800001
03 0018360800001
04 0018310800001
05 0018603200001

