

















DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BG Brugsanvisning / Monteringsvejledning
DK Mode d'emploi / Instructions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjehandleiding
NO Instruksja obstuji / Instrukcija montažu
PL Instruções para uso / Manual de instalação
CZ Návod k použití / Montážní návod
HU Használati útmutató / Szerelési útmutató
SV Bruksanvisning / Monteringsanvisning
ES Modo de empleo / Instrucciones de montaje
RU Руководство пользователя /
Инструкция по монтажу
IT Istruzioni per l'uso / Istruzioni per l'uso
SK Montážny návod / Návod na použítie



Schlösser Armaturen GmbH & Co. KG
Im Dohm 3
57462 Olpe
GERMANY
www.schloesser-armaturen.de
info@schloesser-armaturen.de



0015871800001







- 01 0018182000001
- 02 0018590700002
- 03 0018360800001
- 04 0018310800001
- 05 0018602000001

