













DIN EN 1717





DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
DK Brugsanvisning / Monteringsvejledning
FR Mode d'emploi / Instructions de montage
NL Gebruiksaanwijzing / Handleiding
NO Bruksanvisning / Montasjeveiledning
PL Instrukcja obsługi / Instrukcja montażu
PT Instruções para uso / Manual de instalação
CZ Návod k použití / Montážní návod
HU Használati útmutató / Szerelési útmutató
SV Bruksanvisning / Monteringsanvisning
ES Modo de empleo / Instrucciones de montaje
RU Руководство пользователя /
Инструкция по монтажу
IT Istruzioni per l'uso / Istruzioni per l'uso
SK Montážny návod / Návod na použitie



0013253200001

DIN 1988

DIN 3502

DIN EN 1213

max. 16

max. 90°

bar

°C

- 01 0018203200001
- 02 0018360800001
- 03 0018613200001
- 04 0018193200235

