














DIN EN 1717





DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BG Brúgsanvísing / Monteringsvejledning
DK Mode d'emploi / Instruccions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjeveleiding
NO Instruksja obstuji / Instrukcija montažu
PT Instruções para uso / Manual de instalação
CZ Návod k použití / Montážní návod
HU Használati útmutató / Szerelési útmutató
SV Bruksanvisning / Monteringsanvisning
ES Modo de empleo / Instrucciones de montaje
RU Руководство по пользованию /
Инструкция по монтажу
IT Istruzioni per l'uso / Istruzioni per l'uso
SK Montážny návod / Návod na použítie



0016303200001

01 0018213200001
02 0018590800001
03 0018360800001
04 0018310800001
05 0018213200004
06 0018213200235

