














DIN EN 1717





DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BG Brugsanvisning / Monteringsvejledning
DK Mode d'emploi / Instructions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjehandleiding
NO Instruksja ogstugi / Instruksja montazu
PL Instruções para uso / Manual de instalação
PT Návod k použití / Montážní návod
CZ Használati útmutató / Szerelési útmutató
HU Bruksanvisning / Monteringsanvisning
SV Modo de empleo / Instrucciones de montaje
ES Руководство по монтажу /
RU Инструкция по монтажу
IT Istruzioni per l'uso / Istruzioni per l'uso
SK Montážny návod / Návod na použitie



0016304000001

DIN EN 1213

DIN 3502


DIN 1988



max. 16 bar
0,5 1 5

max. 90°
65°

01 0018214000001
02 0018590800001
03 0018360800001
04 0018310800001
05 0018214000004
06 0018194000235



Schlösser Armaturen GmbH & Co. KG
Im Dohm 3
57462 Olpe
GERMANY
www.schloesser-armaturen.de
info@schloesser-armaturen.de



SCHLÖSSER
Armaturen

