









DIN EN 806
DIN EN 1717
DIN 1988
Global
Standards









- ⓓ Montage- und Bedienanleitung
- ⒸⓃ 安裝及操作指南
- ⒸⓏ Návod k instalaci a k použití
- Ⓔ Instrucciones de montaje y de manejo
- Ⓔⓢ Paigaldamine ja kasutamine
- Ⓕ Instructions de montage et d'utilisation
- Ⓖⓑ Installation and operating instructions
- Ⓖⓡ ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗΣ
- Ⓕ Szerelési és használati utasítás
- Ⓘ Istruzioni di montaggio e per l'uso
- Ⓕⓣ Montavimo ir naudojimo instrukcija
- ⒻⓂ Montāžas un lietošanas instrukcija
- ⒼⓁ Montagehandleiding en Gebruiksaanwijzing
- ⒻⓁ Instrukcja montażu i obsługi
- Ⓕⓡ Instrucțiuni de montaj și utilizare
- Ⓕⓢ Руководство по монтажу и эксплуатации
- ⒻⓀ Návod na montáž a obsluhu
- ⒻⓁⓞ Navodila za montažo in uporabo
- ⒻⓂ Інструкція по монтажу та експлуатації
- ⒻⓂⒺ تعليمات التركيب والتشغيل




Kludi GmbH & Co. KG
Postfach 25 60
D-58685 Menden
Am Vogelsang 31-33
D-58706 Menden

Telefon: (D) +49 (0) 23 73 / 904-0
Telefax: (D) +49 (0) 23 73 / 904-4 65
E-Mail: info@kludi.de
Internet: www.kludi.com




KLUDI




1.




2.




3.



7.



4.



5 Nm