





09 20 91 030



	Chrom	09 20 91 030-00
	Platin gebürstet	09 20 91 030-06
	Platin	09 20 91 030-08
	Messing (23kt Gold)	09 20 91 030-09



Zugstange/-knopf - Chrom

ERSATZTEILE

09 20 91 030



Zugstange/-knopf - Chrom

ERSATZTEILE

09 20 91 030